

ENGLISH

Nut maker

- Clamp
 - Upper form
 - Lower form
 - Ready-to-cook indicator
 - Protective gloves
- ATTENTION!**
- This unit is not a toy! Do not allow children to play with the unit.
 - Read these instructions carefully before using the unit. Use the unit only for intended purposes, as it is stated in this manual. Misusing the unit can lead to the breakage and cause harm to the user or damage to his/her property.
 - This unit is not intended for usage by children. Children can use the unit ONLY under supervision of a person, who is responsible for their safety, and if they are given all the necessary instructions on safety measures and information about danger, which can be caused by improper usage of the unit.

DESCRIPTION

- Clamp
- Upper form
- Power indicator
- Ready-to-cook indicator
- Protective gloves

Attention!

For additional protection it is recommended to install a residual current device (RCD) with nominal operating current not exceeding 30 mA. To install RCD contact a specialist.

NECESSARY SAFETY MEASURES

Read this instruction manual carefully before using the unit and keep it for the whole operating period. Use the unit only for intended purposes, as it is stated in this manual. Misusing the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Do not allow to children use the unit as a toy.
- This unit is not intended for usage by children or disabled persons unless they are given all the necessary instructions by a person who is responsible for their safety on safety measures and information about danger, that can be caused by improper usage of the unit.
- For children safety do not leave polyethylene bags or packaging unattended.
- Attention!** Do not allow children to play with polyethylene bags or packaging film. **Danger of suffocation!**

Before plugging the unit in make sure that unit operating voltage corresponds to the voltage of your mains.

- Power cord is equipped with euro plug - plug it into the socket with relative grounding contact.
- In order to avoid fire do not use adapters for plugging the unit in.
- Do not use the unit outdoors.
- Never leave the operating unit unattended.
- Place the unit on a flat, stable heat-resistant surface with free access to the mains socket.

Install the unit in places with proper ventilation. To avoid fire do not place the unit near curtains or blinds and do not cover it during operation.

- Be careful: the unit body heats up strongly during operation, do not touch hot surfaces.
- Avoid steam output from gaps between the operating forms, be careful, do not bring your hands and do not place open parts of your body near the edges of the operating forms in order to avoid getting of burns.

ATTENTION! Take the nut waffles out of the unit immediately after you made them. Keeping nut waffles in the operating unit for a long time can burn them.

- Never use sharp objects to take waffles out of the nut maker, it can damage the non-stick coating of the operating forms.
- Do not let the power cord hang from the table or counter in contact with hot surfaces or sharp edges of kitchen furniture.
- Do not touch the power plug with wet hands.
- Do not use the unit next to kitchen sink, do not expose it to moisture.
- In order to avoid electric shock do not immerse the power cord, the power plug or the unit itself in water or any other liquids. If it happened DO NOT TOUCH the unit, unplug it immediately and only after that you may take the unit out of water. Apply to the authorized service center for testing and repairing the unit.
- From time to time check power cord and plug integrity.
- You must not use the unit when the power plug or cord is damaged, when it malfunctions or after it was dropped. Do not try to repair the unit by yourself. Contact the authorized service center for all repair issues.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

BEFORE USING THE UNIT FOR THE FIRST TIME

- In case of unit transportation or storage at low temperature it is necessary to keep it for at least two hours at room temperature before switching on.
- Before switching on the unit, make sure that the mains voltage corresponds to the voltage specified on the unit body.
- Clean the non-stick coating with a damp cloth or a sponge and then wipe it dry.
- Before using the unit for the first time, add a little vegetable oil on the non-stick coating of the operating forms (2, 5) and spread it over the whole surface, wipe the surplus oil with a paper cloth. Close the unit and insert the plug into the socket for 5-10 minutes, then unplug the unit.
- Wait until the operating forms (2, 5) cool down completely and remove the remains of vegetable oil.

Note: While the first switching the heating elements burn, therefore occurrence of a small amount of smoke or foreign smell is possible. It is normal and is not a sign of malfunction.

NUT MAKER - 1 PC.

- Protective gloves, big size – 1 pair
- Protective gloves, small size – 1 pair
- Instruction manual – 1 pc.

TECHNICAL SPECIFICATIONS

Power supply: 220-240 V – 50/60Hz
Power: 1300 – 1500 W

The manufacturer preserves the right to change the specifications of the unit without a preliminary notification.

UNIT OPERATING LIFE IS 3 YEARS.

WARRANTY

Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

THIS PRODUCT CONFORMS TO THE EMC-REQUIREMENTS AS Laid down by the Council Directive 89/336/EEC and to the Low Voltage Regulation (73/23/EEC)

INSTRUCTIONS

- On non-stick coating of operating forms (2, 5) lighter usage.
- Insert the plug into the socket, the power indicator (3) will light up, the operating forms (2, 5) will be heated.
- When the preset temperature is reached the ready-to-cook indicator (4) will light up, now you can start making nut waffles.

ENGLISH

- Put on thermal protective gloves (6).
- Lift the clamp (1) and open the upper form (2).
- Wash the hands, touch only the clamp (1). Operating forms (2, 5) get hot during use.
- Carefully pour out the required amount of the preliminarily made dough (see the Recipes examples) from the cavities of the lower form (5).
- Move the upper form (2) down and fix it till the clamp (1) clicks.

Attention!

- Do not allow to pour from the cavities of the lower (5) form, in this case it is necessary to remove the surplus dough and press the forms together.
- Avoid steam output from gaps between the operating forms, be careful, do not bring your hands and do not place open parts of your body near the edges of the operating forms in order to avoid getting of burns.
- During operation the indicator (4) will go out and light up again, showing that the preset temperature of the operating forms (2, 5) is maintained.
- Approximately in 3-4 minutes check the readiness of the nut waffles by lifting the upper form (2), holding the clamp (1). If the nut waffles are not ready, close the unit and wait for some time.
- When the dough gets gold color remove the ready nut waffles carefully using a plastic or a wooden spatula!

ATTENTION! Take the nut waffles out of the unit immediately after you made them. Keeping nut waffles in the operating unit for a long time can burn them.

- Cooking time can change depending on the ingredients used.
- Do not use sharp or metal objects (knives, metal spatulas etc.) to remove nut waffles from the operating unit, it leads to damaging of the non-stick coating of forms (2, 5).
- Slightly grease the operating forms (2, 5) with oil before cooking a new portion of nut waffles.
- When you stop the unit, switch off the unit, removing the plug from the socket. Leave the unit opened and let it cool down.

NECESSARY SAFETY MEASURES

Read this instruction manual carefully before using the unit and keep it for the whole operating period. Use the unit only for intended purposes, as it is stated in this manual. Misusing the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Do not allow to children use the unit as a toy.
- This unit is not intended for usage by children or disabled persons unless they are given all the necessary instructions by a person who is responsible for their safety on safety measures and information about danger, that can be caused by improper usage of the unit.
- For children safety do not leave polyethylene bags or packaging unattended.
- Attention!** Do not allow children to play with polyethylene bags or packaging film. **Danger of suffocation!**

Before plugging the unit in make sure that unit operating voltage corresponds to the voltage of your mains.

- Power cord is equipped with euro plug - plug it into the socket with relative grounding contact.
- In order to avoid fire do not use adapters for plugging the unit in.
- Do not use the unit outdoors.
- Never leave the operating unit unattended.
- Place the unit on a flat, stable heat-resistant surface with free access to the mains socket.

Install the unit in places with proper ventilation. To avoid fire do not place the unit near curtains or blinds and do not cover it during operation.

- Be careful: the unit body heats up strongly during operation, do not touch hot surfaces.
- Avoid steam output from gaps between the operating forms, be careful, do not bring your hands and do not place open parts of your body near the edges of the operating forms in order to avoid getting of burns.

ATTENTION! Take the nut waffles out of the unit immediately after you made them. Keeping nut waffles in the operating unit for a long time can burn them.

- Never use sharp objects to take waffles out of the nut maker, it can damage the non-stick coating of the operating forms.
- Do not let the power cord hang from the table or counter in contact with hot surfaces or sharp edges of kitchen furniture.
- Do not touch the power plug with wet hands.
- Do not use the unit next to kitchen sink, do not expose it to moisture.
- In order to avoid electric shock do not immerse the power cord, the power plug or the unit itself in water or any other liquids. If it happened DO NOT TOUCH the unit, unplug it immediately and only after that you may take the unit out of water. Apply to the authorized service center for testing and repairing the unit.
- From time to time check power cord and plug integrity.
- You must not use the unit when the power plug or cord is damaged, when it malfunctions or after it was dropped. Do not try to repair the unit by yourself. Contact the authorized service center for all repair issues.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

BEFORE USING THE UNIT FOR THE FIRST TIME

- In case of unit transportation or storage at low temperature it is necessary to keep it for at least two hours at room temperature before switching on.
- Before switching on the unit, make sure that the mains voltage corresponds to the voltage specified on the unit body.
- Clean the non-stick coating with a damp cloth or a sponge and then wipe it dry.
- Before using the unit for the first time, add a little vegetable oil on the non-stick coating of the operating forms (2, 5) and spread it over the whole surface, wipe the surplus oil with a paper cloth. Close the unit and insert the plug into the socket for 5-10 minutes, then unplug the unit.
- Wait until the operating forms (2, 5) cool down completely and remove the remains of vegetable oil.

Note: While the first switching the heating elements burn, therefore occurrence of a small amount of smoke or foreign smell is possible. It is normal and is not a sign of malfunction.

NUT MAKER - 1 PC.

- Protective gloves, big size – 1 pair
- Protective gloves, small size – 1 pair
- Instruction manual – 1 pc.

TECHNICAL SPECIFICATIONS

Power supply: 220-240 V – 50/60Hz
Power: 1300 – 1500 W

The manufacturer preserves the right to change the specifications of the unit without a preliminary notification.

UNIT OPERATING LIFE IS 3 YEARS.

WARRANTY

Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

THIS PRODUCT CONFORMS TO THE EMC-REQUIREMENTS AS Laid down by the Council Directive 89/336/EEC and to the Low Voltage Regulation (73/23/EEC)

INSTRUCTIONS

- On non-stick coating of operating forms (2, 5) lighter usage.
- Insert the plug into the socket, the power indicator (3) will light up, the operating forms (2, 5) will be heated.
- When the preset temperature is reached the ready-to-cook indicator (4) will light up, now you can start making nut waffles.

ENGLISH

- Put on thermal protective gloves (6).
- Lift the clamp (1) and open the upper form (2).
- Wash the hands, touch only the clamp (1). Operating forms (2, 5) get hot during use.
- Carefully pour out the required amount of the preliminarily made dough (see the Recipes examples) from the cavities of the lower form (5).
- Move the upper form (2) down and fix it till the clamp (1) clicks.

Attention!

- Do not allow to pour from the cavities of the lower (5) form, in this case it is necessary to remove the surplus dough and press the forms together.
- Avoid steam output from gaps between the operating forms, be careful, do not bring your hands and do not place open parts of your body near the edges of the operating forms in order to avoid getting of burns.
- During operation the indicator (4) will go out and light up again, showing that the preset temperature of the operating forms (2, 5) is maintained.
- Approximately in 3-4 minutes check the readiness of the nut waffles by lifting the upper form (2), holding the clamp (1). If the nut waffles are not ready, close the unit and wait for some time.
- When the dough gets gold color remove the ready nut waffles carefully using a plastic or a wooden spatula!

ATTENTION! Take the nut waffles out of the unit immediately after you made them. Keeping nut waffles in the operating unit for a long time can burn them.

- Cooking time can change depending on the ingredients used.
- Do not use sharp or metal objects (knives, metal spatulas etc.) to remove nut waffles from the operating unit, it leads to damaging of the non-stick coating of forms (2, 5).
- Slightly grease the operating forms (2, 5) with oil before cooking a new portion of nut waffles.
- When you stop the unit, switch off the unit, removing the plug from the socket. Leave the unit opened and let it cool down.

NECESSARY SAFETY MEASURES

Read this instruction manual carefully before using the unit and keep it for the whole operating period. Use the unit only for intended purposes, as it is stated in this manual. Misusing the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Do not allow to children use the unit as a toy.
- This unit is not intended for usage by children or disabled persons unless they are given all the necessary instructions by a person who is responsible for their safety on safety measures and information about danger, that can be caused by improper usage of the unit.
- For children safety do not leave polyethylene bags or packaging unattended.
- Attention!** Do not allow children to play with polyethylene bags or packaging film. **Danger of suffocation!**

Before plugging the unit in make sure that unit operating voltage corresponds to the voltage of your mains.

- Power cord is equipped with euro plug - plug it into the socket with relative grounding contact.
- In order to avoid fire do not use adapters for plugging the unit in.
- Do not use the unit outdoors.
- Never leave the operating unit unattended.
- Place the unit on a flat, stable heat-resistant surface with free access to the mains socket.

Install the unit in places with proper ventilation. To avoid fire do not place the unit near curtains or blinds and do not cover it during operation.

- Be careful: the unit body heats up strongly during operation, do not touch hot surfaces.
- Avoid steam output from gaps between the operating forms, be careful, do not bring your hands and do not place open parts of your body near the edges of the operating forms in order to avoid getting of burns.

ATTENTION! Take the nut waffles out of the unit immediately after you made them. Keeping nut waffles in the operating unit for a long time can burn them.

- Never use sharp objects to take waffles out of the nut maker, it can damage the non-stick coating of the operating forms.
- Do not let the power cord hang from the table or counter in contact with hot surfaces or sharp edges of kitchen furniture.
- Do not touch the power plug with wet hands.
- Do not use the unit next to kitchen sink, do not expose it to moisture.
- In order to avoid electric shock do not immerse the power cord, the power plug or the unit itself in water or any other liquids. If it happened DO NOT TOUCH the unit, unplug it immediately and only after that you may take the unit out of water. Apply to the authorized service center for testing and repairing the unit.
- From time to time check power cord and plug integrity.
- You must not use the unit when the power plug or cord is damaged, when it malfunctions or after it was dropped. Do not try to repair the unit by yourself. Contact the authorized service center for all repair issues.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

BEFORE USING THE UNIT FOR THE FIRST TIME

- In case of unit transportation or storage at low temperature it is necessary to keep it for at least two hours at room temperature before switching on.
- Before switching on the unit, make sure that the mains voltage corresponds to the voltage specified on the unit body.
- Clean the non-stick coating with a damp cloth or a sponge and then wipe it dry.
- Before using the unit for the first time, add a little vegetable oil on the non-stick coating of the operating forms (2, 5) and spread it over the whole surface, wipe the surplus oil with a paper cloth. Close the unit and insert the plug into the socket for 5-10 minutes, then unplug the unit.
- Wait until the operating forms (2, 5) cool down completely and remove the remains of vegetable oil.

Note: While the first switching the heating elements burn, therefore occurrence of a small amount of smoke or foreign smell is possible. It is normal and is not a sign of malfunction.

NUT MAKER - 1 PC.

- Protective gloves, big size – 1 pair
- Protective gloves, small size – 1 pair
- Instruction manual – 1 pc.

TECHNICAL SPECIFICATIONS

Power supply: 220-240 V – 50/60Hz
Power: 1300 – 1500 W

The manufacturer preserves the right to change the specifications of the unit without a preliminary notification.

UNIT OPERATING LIFE IS 3 YEARS.

WARRANTY

Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

THIS PRODUCT CONFORMS TO THE EMC-REQUIREMENTS AS Laid down by the Council Directive 89/336/EEC and to the Low Voltage Regulation (73/23/EEC)

INSTRUCTIONS

- On non-stick coating of operating forms (2, 5) lighter usage.
- Insert the plug into the socket, the power indicator (3) will light up, the operating forms (2, 5) will be heated.
- When the preset temperature is reached the ready-to-cook indicator (4) will light up, now you can start making nut waffles.

DEUTSCH

- Handschuhe anziehen (6).
- Spannvorrichtung (1) heben und die obere Form (2) öffnen.
- Die Hände waschen, nur die Spannvorrichtung (1) berühren. Die Arbeitsformen (2, 5) werden beim Gebrauch heiß.
- Die benötigte Menge des vorbereiteten Teigs (siehe Rezept) in die Aussparungen der unteren Form (5) einlegen.
- Die obere Form (2) herunter und fest auf die Spannvorrichtung (1) drücken.

Achtung!

- Das Gerät ist kein Spielzeug! Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen und materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

DEUTSCH

- Handschuhe anziehen (6).
- Spannvorrichtung (1) heben und die obere Form (2) öffnen.
- Die Hände waschen, nur die Spannvorrichtung (1) berühren. Die Arbeitsformen (2, 5) werden beim Gebrauch heiß.
- Die benötigte Menge des vorbereiteten Teigs (siehe Rezept) in die Aussparungen der unteren Form (5) einlegen.
- Die obere Form (2) herunter und fest auf die Spannvorrichtung (1) drücken.

Achtung!

- Das Gerät ist kein Spielzeug! Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen und materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

NOTWENDIGE SICHERHEITSSCHRISSMAHMEN

Lesen Sie die Betriebsanleitung vor der ersten Nutzung des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

- Es ist nicht gestattet, das Gerät den Kindern als Spielzeug zu geben.
- Lesen Sie diese Betriebsanleitung vor dem ersten Gebrauch des Geräts aufmerksam durch. Nutzen Sie das Gerät nur bestimmungsgemäß, wie dies in der Betriebsanleitung beschrieben ist. Nicht ordnungsgemäße Nutzung des Geräts kann zu seiner Störung führen, einen gesundheitlichen oder materiellen Schaden verursachen und die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

Wichtig!

- Das Gerät ist nicht für den Gebrauch von Kindern geeignet. Dieses Gerät kann von Kindern nur unter Aufsicht der Eltern und unter Aufsicht der Sicherheitsbeauftragten genutzt werden, falls diese Person den Kindern umfangreiche und verständliche Anweisungen über die sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung gegeben hat.

BEWEISUNG

- Speiser
- Obere Form
- Betriebskontrollleuchte
- Betriebsbereitschaftsanzeige
- Untere Form
- Schutzhandschuhe

Achtung!

- Als zusätzlicher Schutz ist es zweckmäßig, den Fingerring mit Nenndruck maximal bis 30 mN im Stromversorgungsnetz aufzustellen. Wenden Sie sich dafür an einen Spezialisten.

